

GreasePaK Refill Cartridge Instructions

GreasePaK Biological Drain Maintenance System by MECHLINE



Box Contents: 5 Litres GreasePaK fluid. For use with Mechline GreasePaK DMI Dispensing Unit only. Mechline GreasePaK MSGD5 fluid uses a complex blend of microorganisms that have been specially formulated to degrade fats, oils and greases in commercial kitchen drains. **IMPORTANT:** Please refer to safety data on reverse.

To fit NEW fluid box:

1
Lay this box on a flat surface and remove circular cardboard cutout.

Pull white plastic connector attached to the internal bag through the cutout hole in the cardboard box. Remove plastic plug on the connector.

2
Carefully hang this box on the spring by the handle.

Carefully connect black GreasePaK connector.

3
Wind black GreasePaK connector **CLOCKWISE** to connect.

Ensure fluid tube loops smoothly to the left.

Carefully wipe up any excess fluid with a disposable cloth and press GreasePaK connector gently back into box before closing door.

To remove EMPTY fluid box:

1
Wind black GreasePaK connector **ANTI-CLOCKWISE** to disconnect.

2
Carefully lift empty box away from spring and recycle components appropriately.

Storage & safety notes:

Store product in a cool dry place.
Wash hands after use.
Avoid ingestion of liquid.
Should product contact skin or eyes rinse thoroughly with clean cool water. Should eye irritation continue, seek medical advice.
In case of ingestion DO NOT induce vomiting and seek medical advice.

WARNING:

Failure to replace fluid boxes when needed could put your drains at risk and violate local water authority requirements for on-site grease management of your operations.

